

MR Chest Pectoralis Protocol

Reviewed By: Lawrence Tang, MD

Last Reviewed: February 2019

Contact: (866) 761-4200, Option 1

General parameters (1.5 T magnets):

For all T1 sequences, please keep TE below 20 (between 10 and 15 if possible); TR 500-600.

For all T2 FS sequences, use equivalent of FSE/TSE. TE of mid to upper 50's is the most ideal for Siemens, 60-65 for GE, and ~ 60 for Toshiba.

It is important to have TE long enough for T2 weighting but not so long that it is signal starved.

For STIR, TI = ~ 135

- Unilateral
- Coverage: proximal half of humerus, medial half of clavicle (including clavicular head) and unilateral half of the sternum

- ax T1
- ax T2 FS
- oblique cor T1 (align with pectoralis major muscle)
- oblique cor T2 FS
- sag T2 FS