

## Sacroiliac Joint MRI

**Reviewed By:** Lawrence Tang, MD

**Last Reviewed:** February 2019

**Contact:** (866) 761-4200, Option 1

### **General parameters (1.5 T magnets):**

For all T1 sequences, please keep TE below 20 (between 10 and 15 if possible); TR 500-600.

For all T2 FS sequences, use equivalent of FSE/TSE. TE of mid to upper 50's is the most ideal for Siemens, 60-65 for GE, and ~ 60 for Toshiba.

It is important to have TE long enough for T2 weighting but not so long that it is signal starved.

For STIR, TI = ~ 135

- cor T1 - whole pelvis
- cor STIR – whole pelvis
- small FOV for sacrum and SI joints (FOV = 22 cm)
- oblique cor T1
- oblique cor T2 FS
- oblique cor T1 FS pre contrast
- oblique cor T1 FS post contrast