

## Sacrum MRI

**Reviewed By:** Lawrence Tang, MD

**Last Reviewed:** February 2019

**Contact:** (866) 761-4200, Option 1

### **General parameters (1.5 T magnets):**

For all T1 sequences, please keep TE below 20 (between 10 and 15 if possible); TR 500-600.

For all T2 FS sequences, use equivalent of FSE/TSE. TE of mid to upper 50's is the most ideal for Siemens, 60-65 for GE, and ~ 60 for Toshiba.

It is important to have TE long enough for T2 weighting but not so long that it is signal starved.

For STIR, TI = ~ 135

- do standard pelvis then add
- small for sacrum and coccyx (FOV = 24 cm)
- sag T1
- sag T2 FS (if FS fails, do STIR)